

# ICW FRAME STYLE CPU MOUNT INSTALLATION

ICWUSA.com, Inc.

If you have any questions, please call 1-800-558-4435

## ATTACH PLATE TO WALL



Locate the stud and mark the top hole, drill 11/64 pilot hole and insert #14 screw and tighten slightly. Using a level, mark the lower hole and drill a pilot hole, insert the second #14 screw, again making sure the unit is level.

**NOTE 1:** ICW supplies #14 wood screws. If installing onto metal studs, you will need to replace with proper metal stud fasteners.



## PLACE CPU INTO FRAME




Using the 3/16 hex key wrench, loosen the 8 screws in the frame just enough so the frame opens easily. Once the frame is open, place the CPU into it, close the frame around the CPU and retighten the screws while holding the CPU in place.

## LOCK CPU TO WALL PLATE

Drop the framed CPU into the wall plate's key holes as shown.


To lock the frame into place, insert the security set screw on the top key-hole and tighten into place.



Place the end caps into the corners of the frame.

## INCLUDED HARDWARE

- 2 wood screws
- 3/16 hex key (5/32 for small CPU)
- 8 end caps (4 for small CPU)




end caps

hex key  
3/16 or  
5/32

wood  
screws

Standard

Large



To help stabilize smaller computers in the frame, larger rubber inserts are available for purchase. Order the **CPU-RUBBERKIT**

HOLE  
TEMPLATE  
FOR  
CPU  
WALL  
MOUNT



**CPU-MINI-T**  
1.0" (2.54 cm) to  
2.2" (5.59 cm) wide;  
8.03" (20.4 cm) to  
12.93" (32.84 cm) in height



**CPU-MINI**  
1.86" (4.72 cm) to  
3.2" (8.13 cm) wide;  
8.03" (20.4 cm) to  
12.93" (32.84 cm) in height




**CPU-2.8**  
2.8" (7.11 cm) to  
5" (12.7 cm) wide;  
10.75" (27.3 cm) to  
18.25" (46.36 cm) in height



**CPU-7**  
7" (17.78 cm) to  
11" (27.94 cm) wide;  
10.75" (27.3 cm) to  
18.25" (46.36 cm) in height



**CPU-5**  
5" (12.7 cm) to  
7" (17.78 cm) wide;  
10.75" (27.3 cm) to  
18.25" (46.36 cm) in height



LEVEL LINE