


ICW LAPTOP TRAY ARM INSTALLATION


ICWUSA.com, Inc.

If you have any questions please call Toll Free 1-800-558-4435



ATTACH QUICK DISCONNECT

- Remove beauty cap on Quick Disconnect block.
- Remove screw using 3/16" hex key.
- Slide keyboard tray into Quick Disconnect block.
- Replace screw and tighten.
- Replace beauty cap.



ATTACH ARM TO MOUNT

Follow instructions below for your style of mount.

MANAGE CABLES

Follow instructions on next page.


IMPORTANT: DO NOT flip up tray when laptop is placed on it.

IF MOUNTING TO THE ULTRA WALL TRACK

MOUNT ULTRA TRACK TO WALL


- Remove small socket head cap screw in the top center of the Wall Track. Remove plastic cover.
- Locate the wall stud and mark the top hole of the Wall Track.
- Drill 11/64 pilot hole, insert #14 screw and tighten slightly. Use a level, mark the lower holes, drill pilot holes and then insert the #14 screws.

NOTE: #14 wood screws are supplied with unit. If installing into metal studs you will need to replace these with proper metal stud fasteners or the provided snap togglers. All hardware used to secure track mount must have a proper countersunk head.




ATTACH SLIDER TO ULTRA TRACK

- Insert slider into wall track.
- Replace the plastic cover and small socket head cap screw.



Once you have adjusted the slider to the desired height, tighten down the Track Slider using the knob on the slider as shown.




IF MOUNTING TO THE WALL

ATTACH WALL PLATE TO WALL

Locate the stud and mark the top hole, drill 11/64 pilot hole and insert #14 screw and tighten slightly. Using a level, mark the lower hold and drill pilot hole, insert #14 screw and, with the unit level, tighten both screws.


NOTE: ICW supplies #14 wood screws. If installing onto metal studs, you will need to replace with proper metal stud fasteners.



LAPTOP TRAY ARM INSTALLATION

IF MOUNTING TO A POLE

ATTACH POLE CLAMP TO POLE




IF MOUNTING TO A DESK

ULTRA CORD MANAGEMENT


Drill a 3/8 hole through the horizontal mounting surface. Push the All Thread bolt on desk mount assembly through the hole in the horizontal surface. Slide large mounting washer over the bolt from underneath and secure in place with 3/8 nylock nut.

Desk Mount Part Number	Stud Length	Maximum Desk Thickness
D0	3.50"	2.47"
D1	3.50"	1.87"
D3	5.50"	1.87"
D5	7.50"	1.87"
D7	10.50"	2.38"



ULTRA CORD MANAGEMENT

1. Prepare all cables to route within the arm by placing them near cavity of arm and bundling together if necessary.
2. Remove cover by unscrewing four screws. Screws are captured by the cover so they cannot fall out. Once screws are disengaged, pull cover out of arm.
3. Place cables within the channel. Do not block the holes where screws will engage in arm.
4. Replace cover and tighten screws. Cables should be able to pull through to desired position if necessary.



WARNING: Provided hook-and-loop fastener strips are intended to hold laptop in place when tray is level. They are NOT intended to secure the laptop when tray is flipped up into stowed position. **CAUTION:** Heat generated by some laptops may soften the glue of the hook-and-loop fasteners.

CLEANING OF THE ICW MOUNTING DEVICE

When cleaning your ICW mounting unit please follow the points below. Proper cleaning of the mounting device will help assure proper function and extend the life of the unit.

1. Any general cleaner is acceptable except degreasers are not recommended near the bearing entrances.
2. Spray cleaner or water on a soft cloth or paper towel and then wipe down the mounts.
3. Do not spray directly at the bearing seams (located at all swivel points) as this could reduce the life of the bearings.

NOTICE: ICWUSA.COM, Inc. provides the appropriate hardware fasteners to match the majority if not all standard monitors and devices. It is the responsibility of the installer / integrator to ensure that the screws and fasteners have the adequate thread engagement. The rule of thumb is that the thread depth is greater than the diameter of the hole or 4 full turns of 360 degrees of thread engagement. It is also the responsibility of the installer / integrator to ensure that they do not damage the monitor or device by using a screw or fastener that is too long for hole and therefore damaging the unit by inserting too far.